



SIDE DOOR STEP
1-REQ. PER CAR
NORTH SIDE OF CAR
AS SHOWN

DESIGN A	MARK NOS. ADDED	B/C/D	PC
DESIGN B	PRICK PUNCH ADDED		2124
DESIGN C	NOTE: STEP TO BE HOT DIPPED		
	BY VALVEUR		
	NOTE: CALLING FOR HOT DIPPED		
	BY VALVEUR REMOVED		
AMERICAN CAR AND FOUNDRY CO.			
4675004			
SIDE DOOR STEP			
DETAILS & APPLICATION			
12-21-48			

a.c.f.